9/9 C.G. KAY 028647-000023

FIG. 8 800 801 Begin 805 802 User Yes Store new target adjustment of value target? 806 No Air mover start 807 Read voltage from airflow sensor, subtract offset 808 Adjust reading for output shift over temperature 812 810 Multiplier Nonlinearity compensation table (or equation) 814 Display measured airflow

BEST AVAILABLE COPY